
Installation Instructions



PE8800 & 12-PE8800 Series

Rim Exit Device for 16, 28, 63, & 66 Functions





This product can expose you to lead which is known to the state of California to cause cancer and birth defects or other reproductive harm. For more information go to www. P65warnings.ca.gov.

A WARNING

Attention Installer: Improper installation may result in damage to the product and void the factory warranty.

Rim Exit Device for 16, 28, 63, & 66 Functions

ASSA ABLOY

Installation Instructions

Screw Chart


SCREW	TOTAL QTY SUPPLIED	WHERE USED
#10-24 X 3/4" FLAT HEAD MACHINE SCREW	4	(4) CHASSIS CORNER MOUNTING HOLES (METAL DOOR)
#10 X 1-1/4" FLAT HEAD WOOD SCREW	4	(4) CHASSIS CORNER MOUNTING HOLES (WOOD DOOR)
#10-24 X 3/4" ROUND HEAD MACHINE SCREW	4	(2) REAR MOUNTING PLATE (METAL DOOR) (2) 649 STRIKE INNER MOUNTING HOLES
#10 X 1-1/4" ROUND HEAD WOOD SCREW	2	(2) REAR MOUNTING PLATE (WOOD DOOR)
#10-24 X 3/4" OVAL HEAD MACHINE SCREW	2	(2) 649 STRIKE OUTER MOUNTING HOLES (METAL FRAME)
#10 X 1-1/4" OVAL HEAD WOOD SCREW	2	(2) 649 STRIKE OUTER MOUNTING HOLES (WOOD FRAME)
#8-32 X 7/16" FLAT HEAD MACHINE SCREW	2	(2) CYLINDER SUPPORT TO CHASSIS (42 & 42T FUNCTIONS ONLY)
#8-32 X 1/4" SOCKET HEAD SET SCREW	1	(1) CYLINDER SUPPORT TO CYLINDER (42 & 42T FUNCTIONS ONLY)
#8-32 X 5/16" W/ #6 OVAL HEAD MACHINE SCREW	6	(4) CHASSIS COVER (2) END CAP
1/4"-20 X 2-3/8" KNURLED FLAT HEAD MACHINE SCREW	2	(2) EXIT TRIM (IF USED)

Rim Exit Device for 16, 28, 63, & 66 Functions

SARGENT ASSA ABLOY

Installation Instructions

Tools Needed






Before installation:

- 1. Install mullion, if used.
- 2. Fit and hang door.
- 3. Check the box's label for the size of the exit device.
- 4. For wood doors, use wood screws and prep accordingly.



The surface of the door where the exit device is to be applied must be flush. Clear away any raised projections to allow exit device to rest on the flat surface of the door. If shim kit is required, contact your distributor.

Note: Please refer to trim and other installation instructions provided in the box.




DOOR HANDS DETERMINED FROM OUTSIDE OF DOOR OR SECURED SIDE

Rim Exit Device for 16, 28, 63, & 66 Functions

Installation Instructions

Exploded View






Rim Exit Device for 16, 28, 63, & 66 Functions

ASSA ABLOY


SARGENT


Installation Instructions






Measure and mark chassis vertical centerline, rail horizontal centerline, and horizontal reference line (bottom chassis mounting holes).









Single Door (Non-Fire Rated)

For 613 strike Dim. "A" = 1-3/4"

For 642 strike Dim. "A" = 1-1/2"







Rim Exit Device for 16, 28, 63, & 66 Functions


ASSA ABLOY


SARGENT

Installation Instructions









A8296A 2/23


thumbpiece clearance (this side only).


Rim Exit Device for 16, 28, 63, & 66 Functions


Installation Instructions


(this side only)













Rim Exit Device for 16, 28, 63, & 66 Functions

ASSA ABLOY

SARGENT





Rim Exit Device for 16, 28, 63, & 66 Functions

SARGENT ASSA ABLOY

Installation Instructions

Rail cutting guide

If the rail doesn't need to be cut, continue to page 10, step 12. If the rail must be cut, follow these steps on page 8 and 9:

Refer to the individual exit device installation instructions for rail cutting requirements / restrictions.

Instructions will vary based on device type and options.

 Determine cut off dimension "X" by subtracting 2-7/8" from dimension "Y". Mark cut off point on mounting rail. (See below.)





Do not cut closer than 1-5/8" from the the front edge of the rail insert.

Information for Cutting Rails			
Rail Sizes	Door Widths		
	Standard	Minimum	
E	32"	24"	
F	36"	33"	
J	42"	37"	
G	48"	43"	


Vertical reference line (\$\mathcal{G}\$ of chassis)

For doors with stile rail, the stile must overlap by 5/16" min.





A. Ensure there isn't a gap between the insert and the dogging slope, and the carrier is flush with the mount.




B. Mark rail at the required cut length.

Rim Exit Device for 16, 28, 63, & 66 Functions


Installation Instructions

Rail cutting guide, continued.







C. Ensure plastic insert support is installed under the cut line.




D. Wrap the rail and insert in masking tape, as shown.



E. Place the rail cutting guide over the masking tape and align it with the cut line. Clamp the cut guide to the rail using a C-clamp.



F. Using a hack saw with a new blade or a chop saw with a metal cutting blade, cut the rail, ensuring that the blade stays pressed against the rail cutting guide.





G. Deburr and smooth all cut edges with a file.


Rim Exit Device for 16, 28, 63, & 66 Functions


Installation Instructions














Rim Exit Device for 16, 28, 63, & 66 Functions


Installation Instructions













Rim Exit Device for 16, 28, 63, & 66 Functions


ASSA ABLOY


SARGENT

Installation Instructions










Rim Exit Device for 16, 28, 63, & 66 Functions


Installation Instructions

SARGENT ASSA ABLOY

24 Install P700 Exit Trim



Insert trim. Ensure lever spindle aligns with bell housing hub and rim cylinder tailpiece aligns with upper spindle hub in chassis (if used).





Secure trim with (2) 1/4 - 20 flat head machine screws through chassis. If used, attach rim cylinder through chassis with screws provided with cylinder.

Rim Exit Device for 16, 28, 63, & 66 Functions

Installation Instructions









Rim Exit Device for 16, 28, 63, & 66 Functions

SARGENT ASSA ABLOY

Installation Instructions




Insert mortise cylinder through blocking ring into cylinder support.




Tighten set screw with 5/64" wrench.

Rim Exit Device for 16, 28, 63, & 66 Functions







Rim Exit Device for 16, 28, 63, & 66 Functions



Rim Exit Device for 16, 28, 63, & 66 Functions



