



Note: Dimensions shown in brackets [] are in millimeters.

Strike location on frames must be adjusted for thickness of door silencers when used

4-7/8" ASA Strike Template For Wood Door Frame