



INSTALLATION INSTRUCTIONS

LR100ARK


ADAMS RITE ELECTRIC LATCH RETRACTION DEVICE KIT

RIM EXIT DEVICE


MODELS: 3700 & 8800

*Visit: sdsec.com/adamsrite
for Installation Video

Retrofit Installation Note: 42" or 48" exit devices that have been modified to fit a 36" or smaller opening, may not have the required space to fit the standard E. L. R. assembly. Always verify the distance from the end of the touchpad to the end rail, and if necessary, consult with the factory for appropriate selection.



ELECTRICAL DATA
 24VDC +/- 10%
 1.5A inrush/200mA holding
 RED (+) BLK (-)
 PATENT #8,851,530



Any suggestions or comments to this instruction or product are welcome. Please contact us through our website or email engineer@sdsecurity.com

Attach the Bracket assembly to the existing Device linkage as shown. Once the Bracket is in place, bend out the tabs so the Bracket assembly will slide easily, without falling out or binding.

