
INSTALLATION INSTRUCTIONS: MINIBLINDS FOR VISION LITES: STANDARD SIZES


- Read and follow the installation requirements of the door manufacturers.
- Cut the hole in the door to correspond to the order size of the vision frame. Assure that the opening is plumb and square.
- Prepare the cutout if required, per the door manufacturers installation instructions.
- 4. Install caulking, tape or compound to both sides of the frame or both sides of glass using listed and approved material appropriate for the fire rating desired. (Air Louvers vision lites do not require glazing tape for installation, however, we recommend application of 1/16" polyethylene glazing tape to reduce breakage caused by metal to glass contact)
- 5. Insert the corridor side frame in the cutout, squaring to door.
- Insert miniblind unit into frame, seating firmly, using setting blocks as needed.
- 7. Inserting 2 of the screws provided in the countersunk holes, carefully align the room side of the frame to the holes in the corridor side of the frame. Screw in enough to hold frame in place for alignment, then insert the other screws lightly. Tighten the screws alternately in a criss-cross pattern to avoid putting more pressure on one side than the other. Do not tighten to the point of deflecting the frame.

Cleaning the Glass: avoid contact with abrasive cleaners and solutions containing corrosive solvents or acid solutions. Clean using a soft cloth and glass cleaner.



STANDARD OPERATOR













INSTALLATION INSTRUCTIONS
MINIBLINDS FOR VISION LITES: STANDARD SIZES

Headquarters: 9702 Newton Ave S, Bloomington, MN 55431 | Ph. 800-554-6077 | Fax: 952-835-2218 | Email: sales@activarcpg.com | www.activarcpg.com | Manufacturing: Bloomington, MN & Commerce, CA Warehouses: Fort Myers FL, Dallas TX, Lancaster PA, Atlanta GA, Chicago, IL, Seattle WA, Omaha NE, Fargo ND