



L400-Series installation instructions

Small Case Mortise Locks

- A** Lockcase and mounting screws
- B** Occupancy indicator
- C** Cylinder compression ring and spring
- D** Inside thumbturn
- E** Blocking ring
- F** Armor front and screws




1 All functions





OR For Functions:

- L460
- L462
- L463
- L464
- L496




2 For Function: L496




Small Case Mortise Locks

- A Lockcase and mounting screws
- B Occupancy indicator
- C Cylinder compression ring and spring
- D Inside thumbturn
- E Blocking ring
- F Armor front and screws




1 All functions



OR For Functions:

- L460
- L462
- L463
- L464
- L496



2 For Function: L496

