

808, 814 TRIM INSTRUCTIONS

(SEE TEMPLATE FOR DOOR PREPARATION)

CYLINDER INSTALLATION




- I. INSERT CYLINDER THROUGH COLLAR AND TRIM PLATE
- 2. SECURE CYLINDER BY TIGHTENING LOCKING NUT



INSERT TAILPIECE INTO THE CAM
SECURE THE CHASSIS TO THE TRIM WITH SCREWS

808, 814 TRIM INSTRUCTIONS

(SEE TEMPLATE FOR DOOR PREPARATION)





DISASSEMBLE

I) REMOVE BACKPLATE, SPINDLE HUB AND TAILPIECE BY REMOVING STUDS.

REASSEMBLE

- I) ROTATE LEVER 180°
- 2) LOCATE SPINDLE HUB INTO THE TRIM PLATE BY PLACING POST BEHIND THE SPRING LEG AS SHOWN BELOW.
- 3) INSTALL BACKPLATE ONTO THE SPINDLE HUB AND BOSS OF TRIM PLATE AND SECURE IT WITH THE STUDS.





STANLEY

Precision Hardware a Division of Stanley Security Solutions, Inc.

www.stanleysecuritysolutions.com