



640011-00

24-V & F-24-V

FALCON®

Surface Vertical Rod Exit Device


Dispositivo de salida con varilla vertical en la superficie

Appareil de sortie de la tige verticale de surface


Installation Instructions

Instrucciones de Instalación

Notice d'installation




Dogging Key **Llave de trinquete** **Œillet vissé**
Use to lock down pushbar
Utilícela para asegurar hacia abajo la barra de empuje
Utilisé pour verrouiller la barre antipanique



! If sexbolts are in box, see Sexbolt Preparation on back page
Si los pernos macho-hembra se encuentran en la caja, consulte la preparación de pernos macho-hembra en la página posterior
Si les colonnettes sont dans la boîte, voir la préparation de colonnettes au verso de la page


1 Draw Exit Device Centerline (☿)
Sacar la línea central de dispositivo (☿)
Tracer l'axe du dispositif de sortie (☿)



40" (101.6 cm) from finished floor
101.6 cm del piso terminado
101.6 cm du plancher fini

2

Rod ☿
Barra ☿
Tige ☿



3" +	2 1/8"
2 1/4"	1 1/4"


Customer Service Servicio al cliente Service à la clientèle
1-877-671-7011 www.allegion.com/us




ALLEGION™

© Allegion 2018
Printed in U.S.A.
640011-00 Rev. 08/18-e

- 3** Mark 2 Holes Using Plastic Template Aligned to ϕ
 Marque 2 orificios utilizando la plantilla de plástico
 alineada a la ϕ
 Marquer 2 orifices en utilisant le gabarit de plastique
 aligné à la ϕ




- 4** If Installing Trim, Go To Trim Instructions
 Se instala la moldura, vaya a las instrucciones de
 molduras
 Pour l'installation d'une garniture, voir les
 instructions de garniture



- 5** Prepare 2 Holes
 Prepare 2 orificios
 Préparer 2 orifices


Metal	Metal	Métal
#7		
1/4" x #20		
OR O OU		
Wood	Madera	Bois
1/8" (3 mm) X 1" (25 mm)		



- 6** Mark Door Using Paper Templates On Back Cover
 Marque la puerta utilizando plantillas de papel en la
 cubierta posterior
 Marquer la porte en utilisant les gabarits de papier au
 verso du couvercle

Flush With Jamb
 Alinee con la Jamba
 À niveau avec le montant

A




B




Flush With Floor
 Alinee con el piso
 À niveau avec le plancher


7

Metal	Metal	Métal
#25		
#10-24		
OR O OU		
Wood	Madera	Bois
1/8" (3 mm) X 1" (25 mm)		




8

Metal	Metal	Métal
#25		
		
#10-24		
		
OR O OU		
Wood	Madera	Bois
1/8" (3 mm) X 1" (25 mm)		
		




10

If Necessary, Reverse Handing
Si es necesario, invierta la operación
Inverser l'assemblage si nécessaire




9


If Necessary, Cut Device
Si es necesario, corte el dispositivo
Couper le dispositif si nécessaire



11




Thru-bolting Trim
Moldura apornada
Vissage transversal
de la garniture




OR
O
OU


Surface Mount
Montaje en la superficie
Montage en surface




12




13



14




15




Metal	Metal	Métal
#25	#10-24	
OR O OU		
Wood	Madera	Bois
1/8" (3 mm)	1" (25 mm) deep/profundidad/profondeur	

16






17



18 Prepare Top Rod Length

Preparar la longitud de la barra en la parte superior
Préparer la longueur de la tige supérieure

Height Altura Hauteur	*Rod Cut Required *La barra Requiere Corte *Coupe de Tige Nécessaire	Extension Required Extensión que se Requiere Longueur Nécessaire
		
6' 8"	4"	—
7' 0"	—	—
7' 2"	10"	1'
7' 6"	6"	1'
7' 10"	2"	1'
8' 0"	—	1'
8' 6"	6"	2'
8' 10"	2"	2'
9' 0"	—	2'
9' 6"	6"	3'
9' 10"	2"	3'
10' 0"	—	3'




*Do not cut threaded end of top rod

*No cortar el extremo roscado de la barra superior

*Ne pas couper l'embout fileté de la tige supérieure


19 Drill New Hole, if Necessary

Perforar un orificio nuevo, si es necesario
Percer un nouvel orifice si nécessaire




22 Test Top Latch Function


Prueba de la función del seguro en la parte superior
Vérifier le fonctionnement du verrou supérieur




23




26




24



27







25




Metal	Metal	Métal
#25	#10-24	
OR O OU		
Wood	Madera	Bois
1/8" (3 mm)	1" (25 mm)	
	deep/profundidad/ profondeur	

28







A Position pushbar guide
Posicione la guía de
la barra de empuje
Guide de positionnement
de la barre antipanique



B Install cover
Instale la cubierta
Installer le couvercle






Sexbolt Perno macho-hembra Colonnnette Preparation Preparación Préparation




If sexbolts are in box, install them at steps 5, 7, & 12 per preparation shown below
Si los pernos macho-hembra se encuentran en la caja, instáloslos en los pasos 5, 7 y 12 conforme a La preparación como se muestra a continuación
Si les colonnnettes sont dans la boîte, installez-les aux étapes 5, 7 et 12 selon la préparation illustrée ci-dessous

Metal/Metal/Métal




Center case
dispositivo
dispositif

Wood/Madera/Bois




Metal/Metal/Métal




End bracket
soporte de montaje
crochet de fin

Wood/Madera/Bois




Metal/Metal/Métal



Top Latch
Seguro superior
Haut de verrouillage

Wood/Madera/Bois



Bottom Bracket
Eje de pedalier
Bas verrou



941367-00

MEL 24/25 Series

FALCON®


Motorized Electric Latch Retraction

Installation Instructions




These instructions are for MEL conversion kits or MEL devices with preinstalled motors.

Parts




MEL motor assembly



MEL cover plate



Do not discard



Motor cable only
(114320)

MEL 6' cable with motor cable
(47269206)



MEL motor mounting
4-20 x 1/4" FHP screws (qty 2)

Allegion Connect accessories available to order

106198 MEL-CON adapter cable with 8-pin connector


040069 MEL motor cable + MEL-CON adapter cable with 8-pin connector



If MEL is preinstalled in the device:

- A. Follow original device instruction up to the point where this end mounting bracket step has been completed.

Mark and Prepare 2 Holes




- B. Complete MEL wiring per steps 15-21 of this instruction.

- C. Return to original device instruction at point you left off, and complete installation.




If installing the MEL conversion kit, follow the instruction steps as written.


1 Remove end cap




2 Remove device end mounting bracket from door




3 Slide back, remove and discard old cover plate



4 Remove center case cover and device from door





5 With device laying on a table or bench, remove the 2 screws that connect mechanism case to center case




i Use long shank screwdriver.

6 Unhook baseplate from center case


- Slide back mechanism case about 2" to access hooking parts.
- Push bar guides will come loose and will need to be reinstalled later.
- Unhook baseplate from center case.



7 Slide baseplate out of mechanism case




8 Remove any existing dogging assembly




9 Secure motor assembly



- a. Turn baseplate assembly upside down so pushpad is resting on a flat surface and motor mounting location is on the left.




- b. Place motor in left hand with LED status sticker facing toward you. Gently extend silver hook arm outward (about 1/2") until you meet some resistance, then hold.




- c. While tilting baseplate assembly away from you slightly, move extended hook arm into position under baseplate. A post will be hanging down from baseplate; the hook arm should sit on the near side of that post. Rotate the motor assembly to hook the arm over the baseplate axle pin that is closest to the baseplate. Do not pull out on motor at this step.




- d. Set motor on flat surface.



- e. Push down firmly on baseplate so it bottoms out against push pad.
- f. While depressing baseplate, lift up motor assembly and guide it along elongated baseplate slot until motor lip slips over baseplate.




- g. Release baseplate. Secure motor assembly with 2 small self-tapping screws (provided).




- h. Turn baseplate and motor assembly right side up.

10 Slide mechanism case onto baseplate


Insert pushbar guide ahead of motor assembly and hold in place (a) while sliding mechanism case onto baseplate (b)




11 Reconnect center case to baseplate via hooking parts




12 Insert remaining pushbar guide (nearest the center case) and slide mechanism case against center case



13 Reattach mechanism case to center case





14 Reattach device to door



15 Complete wiring

i If not wiring at this time, **DO NOT DISCARD CABLE!**
After installing device or conversion kit, if there is room, store the cable inside the mechanism case until the electrical wiring occurs. Otherwise, store the cable in a designated location.

- Drill wire access hole.
- Route furnished 6' MEL two-piece cable thru device end mounting bracket to connect MEL device to power transfer wires.
- Plug cable connector into MEL motor.
- Reinstall end mounting bracket.
- Refer to table below to route proper gauge wires (from electric hinge, EPT, or door loop) to PS900-Series power supply.




PS900-Series power supply with 900-Series option board(s) installed

MEL device used with EPT, Electric Hinge, or Door Loop	
Distance (one way)	Wire Gauge
200'	18AWG
320'	16AWG
500'	14AWG
800'	12AWG

MEL Electrical Load

Voltage: 24 VDC
Current: 1.0 A inrush (0.5 sec)
0.14 A holding

i Power wires to MEL are not polarized.



WARNING

To avoid risk of electric shock, turn off AC power to power supply before installing or wiring option board.


16 Confirm equipment compatibility

MEL is compatible with the following equipment (refer to individual instructions as needed):


- PS900-Series power supplies - PS902, PS904, PS906, PS914
- 900-Series option boards - 900-2RS, 900-4R, 900-4RL

17 Install 900-2RS, 4R, or 4RL option board(s) into power supply

a Review Available 900 series Option Board Mounting Locations (Gray)




PS902




PS904

PS914




PS906




b Plug Option Board Cable into any Available Option Connector



PS902
1 Board



PS904, 914
2 Boards



PS906
3 Boards



c Secure Board(s) with Screws

WARNING

Fire alarm (FA) option board required if MEL is installed in fire exit hardware.

- Notes:**
1. 24 VDC output setting required when MEL device connected.
 2. If installing board in location 2 or 3, rotate board 180°.
 3. Latchbolt retraction of (2) sequenced MEL devices requires more than 1 second to complete.
 4. When powering multiple components, verify that the amperage requirements of all components combined does not exceed the power supply output rating.

18 Connect input and output wires to option board (2RS shown)




19 Check operation

- Activate each input and verify all MEL devices operate properly.
- If any device does not operate properly, see next page for troubleshooting.

20 If necessary, troubleshoot operation (LED is only visible with the mechanism case removed)

Power at the MEL	MEL Response	Condition/Solution
24 VDC	LED - solid green Latchbolt - retracted	Operation normal, latch retracted immediately
	LED - solid red after latchbolt attempts to retract multiple times	Latchbolt cannot fully retract mechanically Remove power. Depress pushbar and make sure latchbolt retracts and extends fully. If necessary, disconnect any vertical rods or mortise lock from device center case, and reapply power. If motor holds, mechanical adjustments may be required per the device instructions.*
	LED - flashing green/red Latchbolt - not retracted	Excessive tamper (while power applied, the pushpad was pulled out at least 3 times) Wait 15 seconds and latchbolt will retract again OR remove and reapply power to clear condition.
24 VDC low	LED - flashing green Latchbolt - retracted	Voltage low during latchbolt retraction (latchbolt retracts at reduced force) Wire length is too long, wire gauge is too small, or power supply has poor regulation.
29 VDC or greater	LED- flashing red Latchbolt - will not retract	Input voltage is too high for proper operation Wrong power supply, power supply defective.
13 VDC or lower		Input voltage is too low for proper operation Wrong power supply, power supply defective or not set to the proper output voltage. To set, remove AC power from power supply, change power supply setting from 12 to 24 VDC, then reapply AC power and verify proper operation.
0 VDC	LED - off Latchbolt - not retracted	No input voltage Problem with the power supply, control switch, or wiring.




*For information about adjusting exit devices, you can find their installation instructions in the support area at www.allegion.com/us or call Technical Services at 1-877-671-7011




21 Install MEL cover plate

i Do **not** cut from recessed end of cover plate


i Install this end first



22 Reinstall end cap



23 Reinstall center case cover



Warnings and Cautions

Warnings look like this:



WARNING

Warnings indicate potentially hazardous conditions, which if not avoided or corrected, may cause death or serious injury.

Cautions look like this:



CAUTION

Cautions indicate potentially hazardous conditions, which if not avoided or corrected, may cause minor or moderate injury. Cautions may also warn against unsafe practices.

Notices look like this:



Notices indicate a condition that may cause equipment or property damage only.

Directions look like this:



Directions identify a step that may or may not apply to your product configuration. It also may direct you to another part of the instruction.